



Crate Liner

Xtend Packaging, Inc.





Open the Intercept Bag and place it flat on the bottom of the crate so that the dark brown side of the Intercept will be facing the part, as above.



Lower the part into the Intercept-lined crate.









Ensure that all parts of the unit are inside the Intercept Bag and apply desiccants to the open airspaces. Xtend will typically provide desiccants as part of the packaging solution. Desiccants should be placed evenly throughout the bag.





Once the unit is desiccated, apply the Intercept top-sheet over the bag, as shown in the picture on the right.





Fold and secure (tape, etc.) the top sheet to the bag to ensure it will remain in place.





Properly and securely close the crate.



Apply Xtend Packaging custom tarp to ensure long-term protection of both the unit inside the crate and the crate itself. Custom tarps can be secured in place with strapping around belt-loops sewn into place.

Tarps prevent water penetration and increase the lifespan of the crate by preventing UV damage and heat warping.

